

# Standpipe – User Guide



The Barossa Council





Example of the Control Panel Layout for the Moculta Standpipe.

The new Standpipes are 24/7 accessible and easy to operate in one complete transaction on your mobile phone. Your mobile phone will need to be able to read QR codes.

You can either set up a PayPal account prior to your first use, or select 'Pay with a Card' to enter your credit card details for payment.

**Note: Users take water from the supply on the understanding that it may not be suitable for human consumption.**

Please refer to the Terms of Use which can be found on The Barossa Council's Website.



premium wine food tourism heritage lifestyle community


1. With your mobile phone, select camera and scan the QR code located on the right hand side of the control panel.

**Casual users:**

1. Scan the QR code
2. Click Access Standpipe
3. Log in with PayPal and add credit
4. You will only be charged for what you use
5. Press the green button, valve will open
6. Press the red button to close the valve



2. Click Access Standpipe



### 3. Log in with PayPal.


If you have a PayPal account – sign in with your account details.

If you do not have a PayPal account – ‘Pay with a Card’ and you can enter your credit card details in this section for payment once water is dispensed.

*The automatic default is \$30.00.*

*This is the maximum amount available for dispensing water in any one transaction.*

*Only the **actual amount used** will be **deducted from your account**.*



**4. Ensure secure connection is made to either the  
50mm male cam lock  
or  
place the fill hose directly into your container.**

**5. Open the appropriate valve as per your discharge method.**





Valve control panel.

**6. Press the green button – the water will flow.**

**7. Press the red button – the water will stop.**

*Only the **actual amount used** will be **deducted from your account.***

**8. Close the appropriate valve as per your discharge method.**

**Disconnect the 50mm cam lock if utilised.**

**9. Please leave the Standpipe area in an appropriate condition ready for the next user.**